

7

**No output from control unit**

Check to see if power source voltage is present at terminals (12) and (21) of control unit when starter switch is turned to ON position

NO

OK

Check operation of meters and indicators with starter switch turned to ON position

Test continuity across control unit terminals (11), (20) and ground

NO

OK

NO

OK

Check function of starter switch  
Correct or replace wiring between starter switch and battery

Check to see if power voltage is present at main relay wiring "1.25BW" and "1.25BL" when starter switch is turned to ON position

Correct or replace wiring

Replace control unit

If fusible link wire "1.0B" at battery has been blown out, circuit might have been overloaded due to short-circuit  
Correction is to replace fusible link wire after locating cause of short-circuit and repairing

NO  
to 8

OK  
Correct or replace wiring between main relay and control unit