

15

Air-fuel mixture too rich

Listen for noise to see if fuel injector is functioning properly

NO

Fuel injector stuck in open position

Replace defective fuel injector

Sticking of fuel injector is often caused by rust formation. Check quality of fuel in use and check for presence of water in fuel. Drain and refill fuel system as necessary and replace fuel injectors.

OK

Check fuel pressure

NO

Fuel pressure too high

to 13

NO

Fuel pressure lowers immediately after engine stalling

Make a test with pressure regulator asm replaced

OK

Further checks unnecessary

NO

Replace defective fuel injector

OK

Check resistance in water temperature sensor

OK

Replace sensor

NO

Check fuel injector for leakage

OK

Replace control unit