

22

Abnormal fuel combustion

Check that hoses on the intake side are free from damage and are connected properly, intake manifold is not loose, gaskets are free from damage which permits air to be drawn into engine, and that oil filler cap and oil level gauge rods are installed properly

Check condition of spark plug

