

10

Fuel pump does not operate when cranking engine with starter

Check operation of fuel pump with power voltage applied directly to fuel pump relay terminal "12.5BL"

NO

OK

Make a test by applying power source voltage directly to fuel pump using a jumper cable

NO

OK

Check grounding of fuel pump

Correct or replace wiring between fuel pump relay and fuel pump

NO

OK

Correct or replace grounding wire

Replace fuel pump

Check to see if there is continuity between switch side connector terminals "3W" and "3WB" when starter switch is turned to position of START with harnesses disconnected at connector

OPEN

CONTINUITY

Replace starter switch

Correct or replace wiring between starter switch and fuel pump