

12

Fuel pressure too low

Make a test by applying power source voltage directly to fuel pump using a jumper wire

NO

OK

Make a test with pressure regulator replaced

Make a test by applying battery voltage directly to fuel pump relay terminal "1,25BY" with engine running at idle

NO

OK

Check fuel pump inlet side hose for restrictions

Further checks unnecessary

NO

OK

Clean or replace hose

Check fuel pressure line for collapse and restrictions

NO

OK

Clean or replace pressure line

Replace fuel pump assembly

NO

OK

Check to see if battery voltage is present at relay terminal "1,25BL" when engine is idling

Correct or replace wiring between relay and pump

NO

OK

Correct or replace wiring between relay and battery

Replace fuel pump relay