

8

**No output from main relay**

Check to see if power source voltage is present at main relay terminal "0.85BY" when starter switch is turned to ON position

NO

Correct or replace wiring between relay and starter switch

OK

Check to see if power voltage is present at main relay terminals "1.25W"

NO

Correct or replace wiring between relay and battery

If fusible link wire "0.4G" or "1.0B" at battery has been blown out, circuit might have been overloaded due to short-circuit

Correction is to replace fusible link wire after locating cause of short-circuit and repairing

OK

Test continuity across relay terminal "0.5BG" and ground

NO

Correct or replace wiring or diode; main relay

OK

Replace main relay